

Learn to hem your pants, fix a seam, or make your own t-shirt. You can repair instead of replace in a few easy steps!



 Learn More




## START HERE

Locate and familiarize yourself with: power, thread, bobbin, balance wheel, stitch dial, presser foot, needle, feed dogs, and tension.

## THREAD IT

Prepare the thread and bobbin.



## GET SEWING

Place your fabric, lower the presser foot, and depress the foot pedal. Release the pedal to stop. Raise the presser foot to release your fabric.



Learn to hem your pants, fix a seam, or make your own t-shirt.  
You can repair instead of replace in a few easy steps!

- 1** Raise presser foot and position the fabric next to a seam guide line on the needle plate. 5/8" (1.6 cm) is most common.
- 2** Lower the needle to the point where you want to start.
- 3** Lower the presser foot and pull the threads toward the back. Gently hold the two threads for the first few stitches so they do not get caught in the machine.
- 4** Lightly press the foot pedal. Gently guide the fabric along a seam guide line letting the fabric feed naturally. Never push or pull the fabric. Let the machine be the guide.
- 5** To fasten the ends of a seam, press the reverse stitch button and sew several reverse stitches.
- 6** Raise the presser foot.
- 7** Remove the fabric, draw the threads to the back and cut them with the thread cutter.



Want to learn more?  
Watch a video tutorial



 Learn More